



GETTING STARTED

GETTING TO KNOW YOUR Vx502 MULTIFUNCTION CONTROLLER (MFC)



- 1 MFC-MULTIFUNCTIONAL CONTROLLER
- 2 SRC RED = AUX IN MODE / BLUE = BT MODE
- 3 VOLUME UP
- 4 NEXT TRACK / FAST FORWARD
- 5 PLAY / PAUSE
- 6 VOLUME DOWN
- 7 PREVIOUS TRACK / FAST REWIND

BLUETOOTH OPERATION



PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION

1. Power on the **VX502** by short press the **SRC** (2) button, the Bluetooth blue LED will be switched on, a confirmation tone will be heard, signaling that **VX502** is now ready for Bluetooth pairing.

2. Now that the **VX502(VELEX)** is in pairing mode:

Android users:

- a. Go into the Setting Menu of your device
- b. Enter the Bluetooth Menu and press SCAN
- c. **VX502(VELEX)** will now be displayed under AVAILABLE DEVICES
- d. If prompted, enter passcode: "0000"

iOS users:


- a. Go into the Setting Menu of your device
 - b. Enter the Bluetooth Menu
 - c. **VX502(VELEX)** will now be displayed
 - d. If prompted, enter passcode: "0000"
3. If the **VX502** is not seen, repeat the above steps to refresh the "Device List".
4. When the connection is successful, you are now ready to stream music from your devices favorite media player to the **VX502**
5. Press and hold SRC button to power off **VX502**.



Tips: To avoid battery exhaustion be sure to run the vehicles engine while using this product. Using this product without running the engine can drain the battery.


GETTING STARTED

GETTING TO KNOW YOUR Vx502 MULTIFUNCTION CONTROLLER (MFC)



- 1 MFC-MULTIFUNCTION CONTROLLER
- 2 SRC RED = AUX IN MODE / BLUE = BT MODE
- 3 VOLUME UP
- 4 NEXT TRACK / FAST FORWARD
- 5 PLAY / PAUSE
- 6 VOLUME DOWN
- 7 PREVIOUS TRACK / FAST REWIND

BLUETOOTH OPERATION



PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION

1. Power on the **VX502** by short press the **SRC** (2) button, the Bluetooth blue LED will be switched on, a confirmation tone will be heard, signaling that **VX502** is now ready for Bluetooth pairing.

2. Now that the **VX502**(VELEX) is in pairing mode:

Android users:

- a. Go into the Setting Menu of your device
- b. Enter the Bluetooth Menu and press SCAN
- c. **VX502**(VELEX) will now be display under AVAILABLE DEVICES
- d. If prompted, enter passcode: "0000"


iOS users:

- a. Go into the Setting Menu of your device
 - b. Enter the Bluetooth Menu
 - c. **VX502**(VELEX) will now be displayed
 - d. If prompted, enter passcode: "0000"
3. If the **VX502** is not seen, repeat the above steps to refresh the "Device List".
4. When the connection is successful, you are now ready to stream music from your devices favorite media player to the **VX502**
5. Press and hold SRC button to power off **VX502**.



Tips: To avoid battery exhaustion be sure to run the vehicles engine while using this product. Using this product without running the engine can drain the battery.


BLUETOOTH OPERATION



RECONNECTION

1. Power on the **VX502** and your last paired Bluetooth Device;
2. The unit will now automatically reconnect;
3. If your device was previous paired with **VX502**, but it wasn't the last paired device:
 - a. Ensure no other devices are currently paired
 - b. Enter the **Bluetooth Menu** on your device being paired
 - c. **VX502** will display under **AVAILABLE DEVICES**
 - d. Choose the **VX502** to reconnect
4. If the device is out of range from **VX502**, it will disconnect automatically:
 - a. To reconnect once device is back in range, press the **Power** **2** button once
 - b. The **VX502** will now reconnect to the device, a confirmation tone will be heard from the speakers.

STREAMING MUSIC



MULTIFUNCTIONAL CONTROLLER BLUETOOTH OPERATION

1. Press the **5** **PLAY/PAUSE**, once to start playing music or press the **PLAY** button from your device touch screen, pressing again to **PAUSE**
2. To skip songs or advance, press the **NEXT TRACK** **4** button, press and hold to **FAST FORWARD**
3. To select the previous song, press the **PREVIOUS TRACK** **7** button, press and hold to **FAST REWIND**

VOLUME CONTROL

1. To raise the **VOLUME** press **UP** **3** button
2. To lower the **VOLUME** press **DOWN** **6** button



Tips: Turn the **BLUETOOTH** volume level on your device to its 100% level




velox



velox

AUX-IN-INPUT



AUX-IN OPERATION

VX502 can play audio from any device that has a pair of RCA output

1. Power on the VX502 by short press **SRC** (2) button
2. Short press the **SRC** (2) button again once, the controller LED lighting will change to **RED**, indicating the system is in **AUX-IN** mode.
3. **Bluetooth** devices will remain paired even in **AUX-IN MODE**
4. Connect the integrated **RCA AUX-IN** cable on the amplifier (if you have a 3.5mm jack device, please use the 3.5mm to RCA adaptor, 3.5mm to RCA adaptor is not included)
5. Route the audio wires back to a convenient storage place, secure your device.

VOLUME CONTROL

1. To raise the **VOLUME** press **UP** (3) button
2. To lower the **VOLUME** press **DOWN** (6) button
3. To **MUTE / UN-MUTE** the **VOLUME** press **PLAY / PAUSE** (5) button



Tips: Turn the **HEADPHONE** volume level on your device to its 100% level

TROUBLE SHOOTING GUIDE

TROUBLE	CAUSE	SOLUTION
Unit will not turn on	The fuse is blown	Check / replace the fuse
	Ignition not engaged	Turn ignition to on position
	Blown speaker	Replace faulty speaker
No sound is heard	Volume is low / muted	Press the volume level up
	Device is paused or muted	Check your devices playing / volume status
Can not pair Bluetooth	The Bluetooth function of the device is not enabled	Refer to the user manual of the device for how to enable the Bluetooth function
The audio quality is poor after connection with a Bluetooth enabled device	The Bluetooth reception is poor	Move the device closer to the audio system or remove any obstacle between the device and the systems antenna
Unit has become unresponsive	Power glitch or interference	Disconnect power for 10 seconds to reset